


**HONDA CR250  
BOTTOM END**



CATALOG #	ITEM ID	DESCRIPTION
CRANK 72	Hond0541	Stock Honda Crank
CRANK 74	BAM 0542A	74mm BAM Lt Wt Crank
CRANK 76	BAM 0545A	76mm BAM Lt Wt Crank
LEFT ENGINE CASE	Hond0355	Left Honda Case
RIGHT ENGINE CASE	Hond0350	Right Honda Case
RTS-1	Hond0671	Crank Shaft Bolt
RTS-2	Hond0674	Crank Shaft Washer
RTS-3	Hond0677	Crank Shaft Gear
RTS-4	Hond0672	Honda Crank Shaft Collar
RTS-5	Hond0504	86 - 02 Right Crank Seal
RTS-6	Hond0186	Right Main Shaft Bearing
RTS-7	Hond0190	Right Counter Shaft Bearing
RTS-8	Hond0434	92 - 00 Center Case O-Ring
RTS-9	Hond0532	Large Case Dowel
RTS-10	Hond0730	Honda Oil Drain Plug
RTS-11	Hond0731	Honda Oil Drain Plug Washer
RTS-12	Hond0638	Shift Fork Shaft Long
RTS-13	Hond0635	Shift Fork Shaft Short
RTS-14	Hond0174	4 Left Shift Fork
RTS-15	Hond0176	4 Right Shift Fork
RTS-16	Hond0172	4 Center Shift Fork
RTS-17	Hond0644	Gear Shifter Drum
RTS-17b	Hond0648	Right Shifter Drum Bearing
RTS-18	Hond0668	Shaft Drum Bearing Plate
RTS-20	Hond0695	Flywheel Keyway
RTS-22	Hond0410	86 - 91 Center Gasket
RTS-22	Hond0412	92 - 01 Center Gasket
RTS-24	Hond0735	Breather Hose

CATALOG #	ITEM ID	DESCRIPTION
RTS-26	Hond0500	84 - 91 Left Crank Seal
RTS-26	Hond0502	92 - 02 Left Crank Seal
RTS-27	Hond0528	Cylinder Dowel
RTS-28	Hond0184	Left Main Shaft Bearing
RTS-29	Hond0710	Counter Shaft Bearing Plate Screws
RTS-30	Hond0188	Left Counter Shaft Bearing
RTS-31	Hond0665	Counter Shaft Bearing Plate
RTS-32	Hond0450	Shift Shaft Seal
RTS-33	Hond0680	Counter Shaft Seal
RTS-34	Hond0181	Counter Shaft Collar O-Ring
RTS-35	Hond0180	Counter Shaft Collar
RTS-37	Hond0564	Honda Sprocket Washer
RTS-38	Hond0562	Honda Sprocket Bolt
RTS-39	Hond0534	84 - 91 Front Case Stud
RTS-39	Hond0535	92 - 01 Front Case Stud
RTS-40	Hond0533	84 - 86 Rear Case Stud
RTS-40	Hond0533-76	76mm Rear Case Stud
RTS-40	Hond0533R	87 - 01 Rear Case Stud
RTS-100	Hond0540	88 - 00 Rod Kit No Thrust Washer
RTS-150	Hond0516	Honda Main Bearing
RTS-151	Hond0516CB	Ceramic Honda Main Bearing
SPROCKET	Hond0200	Gear 12 88 - 01
SPROCKET	Hond0202	Gear 13 86 - 87
SPROCKET	Hond0203	Gear 13 88 - 01
SPROCKET	Hond0205	Gear 14 86 - 87
SPROCKET	Hond0206	Gear 14 88 - 01
SPROCKET	Hond0208	Gear 15 86 - 87
SPROCKET	Hond0209	Gear 15 88 - 01
SPROCKET	Hond0210	Gear 16 88 - 01