


HONDA CR250 SIDECASE & SHIFT ASSEMBLY

(*92-'00 SPECIFY YEAR
WHEN ORDERING PARTS)



| CATALOG # | ITEM ID | DESCRIPTION |
|-----------|-----------|-------------------------------------|
| RTS-54 | Hond0590 | Center Gear Shifter Drum |
| RTS-55 | Hond0639A | Shift Drum Stopper Spring |
| RTS-56 | Hond0595 | Clutch Hub Lock Washer |
| RTS-57 | Hond0597 | Clutch Hub Nut |
| RTS-58 | Hond0640 | Shift Drum Stopper Arm Pivot Bolt |
| RTS-59 | Hond0639 | Drum Stopper |
| RTS-60 | Hond0640A | Shift Drum Stopper Arm Pivot Washer |
| RTS-61 | Hond0715 | Shift Shaft Snap Ring |
| RTS-63 | Hond0711 | Gearshift Spindle |
| RTS-64 | Hond0712 | Gearshift Return Spring |
| RTS-65 | Hond0720 | Shift Shaft Washer |
| RTS-66 | Hond0647A | Roller 4 X 8 (Shift Drum Pin) |
| RTS-67 | Hond0650 | Gear Shift Return Spring Pin |
| RTS-68 | Hond0656 | A - Pawl |
| RTS-69 | Hond0647 | Shifter Gearshift Drum |
| RTS-70 | Hond0641 | Drum Shifter Collar |
| RTS-71 | Hond0645 | Guide Plate |
| RTS-72 | Hond0653 | B - Pawl |
| RTS-73 | Hond0659 | Pawl Spring |
| RTS-75 | Hond0662 | Pawl Plunger 84 - 93 |
| RTS-75 | Hond0663 | Pawl Plunger 94 - 00 |

| CATALOG # | ITEM ID | DESCRIPTION |
|-----------|----------|------------------------------------|
| RTS-76 | Hond0575 | Honda 86 - 91 Water Pump Gasket |
| RTS-76 | Hond0576 | 92 - 99 Water Pump Gasket |
| RTS-77 | Hond0406 | 86 - 91 Rightside Gasket |
| RTS-77 | Hond0408 | 92 - 01 Rightside Gasket |
| RTS-78 | Hond0573 | Honda Water Pump Cover |
| RTS-79 | Hond0530 | Honda Case Dowel |
| RTS-80 | Hond0570 | Honda Water Pump Drain Plug |
| RTS-80-1 | Hond0571 | Honda Water Pump Drain Plug Washer |
| RTS-85 | Hond0691 | Water Pump Separator |
| RTS-86 | Hond0586 | Honda Clutch Cover O-Ring |
| RTS-87 | Hond0583 | Honda Clutch Cover |
| RTS-88 | Hond0356 | Right Crankcase Cover |
| RTS-89 | Hond0689 | Water Pump Impeller |
| RTS-90 | Hond0690 | Water Pump Washer |
| RTS-91 | Hond0688 | Outer Water Pump Seal |
| RTS-92 | Hond0683 | Inner Water Pump Seal |
| RTS-93 | Hond0692 | Water Pump Bearing |
| RTS-94 | Hond0572 | Honda 98 - 99 Water Pump Gear |
| RTS-99 | Hond0732 | Honda Oil Fill Cap |
| RTS-100 | Hond0734 | Honda Oil Fill Cap O-Ring |